

FLAT RIM



81075

51607



FLAT RIM
51030 White



51030-5495
33cm FLAT RIM PLATE
D336mm/H17mm

51030-5461
30cm FLAT RIM PLATE
D302mm/H17mm

51030-5513
29cm FLAT RIM PLATE
D291mm/H20mm

51030-5462
27cm FLAT RIM PLATE
D272mm/H16mm



51030-5514
23cm FLAT RIM PLATE
D236mm/H13mm

51030-5463
21cm FLAT RIM PLATE
D214mm/H12mm

51030-5472
16cm FLAT RIM PLATE
D164mm/H12mm

51030-9787
23cm BUTTER TRAY
L235mm/S150mm/H14mm

FLAT RIM
51030 White



51030-5239
25cm SOUP PLATE
D252mm/H38mm



51030-5464
23cm SOUP PLATE
D237mm/H33mm/270cc



51030-3555
14cm FRUIT BOWL
D141mm/H58mm/540cc



51030-3556
23cm VEGETABLE BOWL
D227mm/H94mm/1,940cc



51030-4667
CREAMER JUG 290cc
L145mm/S78mm/H102mm/290cc



51030-4660
CREAMER JUG 170cc
L126mm/S65mm/H83mm/175cc



51030-4666
CREAMER JUG 100cc
L100mm/S53mm/H70mm/100cc



51030-4659
SUGAR BOWL
W/COVER 250cc
L108mm/S87mm
H83mm/250cc



51030-4607
SUGAR BOWL
D97mm/H97mm/400cc



51030-4596
SUGAR BOWL
W/HANDLE
L144mm/S103mm
H96mm/410cc



51030-4597
CREAMER JUG 300cc
L125mm/S84mm
H74mm/300cc



51030-4595
COFFEE POT W/COVER
L222mm/S110mm
H210mm/1,430cc



51030-2762
TEA/COFFEE CUP
L111mm/S87mm
H61mm/270cc



51030-2876
ESPRESSO CUP
L80mm/S59mm
H53mm/100cc



51030-2762
TEA/COFFEE CUP
L111mm/87mm
H61mm/270cc



51030-2876
ESPRESSO CUP
L80mm/S59mm
H53mm/100cc



51030-2887
TEA/COFFEE CUP
L125mm/S101mm
H68mm/250cc



51030-2888
ESPRESSO CUP
L93mm/S74mm
H60mm/130cc

51030-5561
COMMON SAUCER
D166mm/H11mm

51030-5562
ESPRESSO SAUCER
D126mm/H11mm

51030-5706
16cm SAUCER
D157mm/H20mm

51030-5707
ESPRESSO SAUCER
D112mm/H14mm

51030-5706
16cm SAUCER
D157mm/H20mm

51030-5707
ESPRESSO SAUCER
D112mm/H14mm

FLAT RIM
51030 White



51030-4656
COFFEE POT W/COVER 820cc
L232mm/S93mm
H166mm/820cc



51030-4655
COFFEE POT W/COVER 600cc
L209mm/S92mm
H146mm/600cc



51030-4658
TEA POT W/COVER 950cc
L261mm/S120mm
H140mm/950cc



51030-4657
TEA POT W/COVER 710cc
L231mm/S106mm
H122mm/710cc