



8740-1136
30cm PLATE
D309mm/H30mm

8740-1120
27cm PLATE
D276mm/H31mm

8740-1131
25cm PLATE
D253mm/H27mm

8740-1121
23cm PLATE
D233mm/H24mm

8740-1122
21cm PLATE
D218mm/H24mm

8740-1138
19cm PLATE
D196mm/H22mm

8740-1123
17cm PLATE
D177mm/H19mm



8740-1171
23cm RIM SOUP PLATE
D240mm/H35mm/350cc



8740-1124
20cm COUPE SOUP BOWL
D206mm/H35mm/570cc



8740-1125
15cm FRUIT BOWL
D150mm/H29mm



8740-1133
17cm BOWL
D168mm/H42mm



8740-1170
23cm BUTTER TRAY
L244mm/S146mm/H21mm



8740-2540
COFFEE CUP
L113mm/S84mm/H63mm/210cc



8740-2541
TEA CUP
L121mm/S97mm/H60mm/230cc



8740-2548
ESPRESSO CUP
L91mm/S67mm/H60mm/110cc



8740-2549
BOUILLON CUP
L131mm/S109mm/H54mm/290cc



9772-9314
SALT SHAKER
(3HOLES)
L53mm/S40mm
H72mm



9772-9313
PEPPER SHAKER
(5HOLES)
L53mm/S40mm
H72mm

8740-1128
COMMON SAUCER
D159mm/H23mm

8740-1128
COMMON SAUCER
D159mm/H23mm

8740-1132
ESPRESSO SAUCER
D108mm/H16mm

8740-1128
COMMON SAUCER
D159mm/H23mm



8740-4486
COFFEE POT W/ COVER
L272mm/S132mm
H202mm/1,350cc



8740-4472
TEA/COFFEE POT W/ COVER
L247mm/S122mm
H183mm/960cc



8740-4475
TEA POT W/ COVER
L217mm/S120mm
H140mm/600cc



8740-4471
SUGAR BOWL W/ COVER
L150mm/S104mm
H113mm/290cc



8740-4470
CREAMER JUG 170cc
L120mm/S70mm
H80mm/170cc



8740-3337
23cm SALAD BOWL
L272mm/S233mm
H91mm/1,980cc



8740-3375
CASSEROLE W/ COVER
L335mm/S251mm
H197mm/3,615cc



8740-1126
41cm OVAL PLATTER
L408mm/S288mm/H31mm

8740-1167
38cm OVAL PLATTER
L382mm/S270mm/H35mm