





51672-5745
27cm PLATE
D273mm/H25mm



51672-5746
23cm PLATE
D238mm/H21mm



51672-5747
16cm PLATE
D164mm/H20mm



51672-35971
19cm BOWL
D191mm/H80mm/1,100cc



51672-5752
24cm SOUP PLATE
D243mm/H50mm



51672-5749
17cm BOWL
D174mm/H46mm



51672-28971
SOUP BOWL
D118mm/H64mm/370cc



51672-9836
DESSERT CUP
D85mm/H73mm/170cc



51672-2894
COFFEE CUP
L104mm/D78mm/H64mm/225cc



51672-2895
ESPRESSO CUP
L82mm/D59mm/H55mm/110cc



51672-2893
CAPPUCCINO CUP
L130mm/D103mm/H63mm/370cc



51672-2896
BOUILLON CUP
L160mm/S118mm
H64mm/370cc



51672-4676
CREAMER JUG 230cc
L118mm/S80mm/H75mm/230cc

51672-5753
17cm SAUCER
D170mm/H18mm

51672-5754
13cm SAUCER
D133mm/H15mm

51672-5753
17cm SAUCER
D170mm/H18mm



51672-4681
TEA POT W/ COVER 850cc
L220mm/S128mm/H127mm/850cc



51672-4673
SAUCE BOAT 450cc
L197mm/S92mm/H91mm/450cc

51672-4674
SAUCE BOAT 220cc
L156mm/S44mm/H77mm/220cc

51672-4675
SAUCE BOAT 90cc
L119mm/S47mm/H58mm/90cc



51672-4680
SUGAR BOWL
W/ COVER 220cc
D90mm/H80mm/220cc



51672-4679
MARMALADE POT
W/ COVER 90cc
D70mm/H66mm/90cc



51672-9837
SALT SHAKER (1 HOLE)
51672-9838
PEPPER SHAKER (3 HOLES)
D42mm/H42mm