



9795-1440
27cm DINNER PLATE
D269mm/H26mm

9795-1522
25cm DINNER PLATE
D255mm/H24mm

9795-1448
23cm FISH PLATE
D236mm/H22mm

9795-1441
20cm SALAD PLATE
D199mm/H21mm

9795-1442
16cm B.B.PLATE
D167mm/H18mm



9795-1024
24cm PASTA PLATE
D240mm/H47mm

9795-1644
23cm RIM SOUP PLATE
D234mm/H35mm/430cc

9795-1449
19cm COUPE SOUP BOWL
D191mm/H44mm/610cc

9795-1450
16cm CEREAL BOWL
D167mm/H44mm

9795-1451
14cm FRUIT BOWL
D143mm/H31mm



9795-2257
TEA CUP
L115mm/S91mm/H55mm/230cc

9795-2260
COFFEE CUP
L102mm/S73mm/H66mm/200cc

9795-2258
ESPRESSO CUP
L87mm/S66mm/H51mm/110cc

9795-2286
AMERICAN COFFEE CUP
L104mm/S80mm/H70mm/260cc

9795-2259
BOUILLON CUP
L146mm/S101mm/H55mm/300cc

9795-1452
COMMON SAUCER
D155mm/H21mm

9795-1452
COMMON SAUCER
D155mm/H21mm

9795-1453
ESPRESSO SAUCER
D125mm/H20mm

9795-1452
COMMON SAUCER
D155mm/H21mm

9795-1452
COMMON SAUCER
D155mm/H21mm



9795-4237
TEA POT W/COVER(3-P)
L174mm/S123mm/H128mm/830cc

9795-4236
TEA POT W/COVER(1-P)
L155mm/S105mm/H114mm/500cc

9795-4356
COFFEE POT W/COVER(4-P)
L173mm/S152mm/H153mm/970cc

9795-4239
COFFEE POT W/COVER(1-P)
L139mm/S91mm/H120mm/430cc

9795-4345
SUGAR BOWL W/COVER
D86mm/H84mm/260cc



9795-4238
MILK POT
L120mm/S87mm/H101mm/340cc

9795-4286
CREAMER JUG 190cc
L96mm/S74mm/H69mm/190cc

9795-4287
CREAMER JUG 90cc
L76mm/S59mm/H52mm/90cc

9795-4235
MILK PITCHER(L)
D67mm/H74mm/160cc

9795-9278
MILK PITCHER(M)
D53mm/H58mm/70cc

9795-9502
MILK PITCHER(S)
D46mm/H47mm/40cc