

# FLAT 51090 White



51090-5540  
30cm FLAT PLATE  
D290mm/H24mm



51090-5428  
17cm FLAT PLATE  
D170mm/H17mm



51090-5541  
11cm FLAT PLATE  
D113mm/H16mm



51090-27702  
COVER FOR 17cm SALAD BOWL  
D172mm/H30mm

51090-27701  
17cm SALAD BOWL  
D168mm/H50mm/610cc



51090-2764  
TEA CUP  
L118mm/S101mm/H59mm/210cc



51090-2764  
TEA CUP  
L118mm/S101mm/H59mm/210cc



51090-2766  
COFFEE CUP  
L102mm/S81mm/H76mm/210cc



51090-2768  
ESPRESSO CUP  
L83mm/S68mm/H58mm/110cc

51090-5542  
FLAT SAUCER  
D136mm/H15mm

8531-1946  
TEA/COFFEE SAUCER  
D146mm/H21mm

8531-1946  
TEA/COFFEE SAUCER  
D146mm/H21mm

8531-1222  
ESPRESSO SAUCER  
D124mm/H18mm



51090-27852  
COVER FOR BOUILLON CUP  
D126mm/H36mm

51090-27851  
BOUILLON CUP  
L159mm/S122mm/H56mm/270cc

8531-1217  
SAUCER  
D158mm/H19mm



51090-27652  
COVER FOR SOUP CUP  
D105mm/H26mm

51090-27651  
SOUP CUP  
D101mm/H59mm/210cc

51090-5542  
FLAT SAUCER  
D136mm/H15mm



51090-27652  
COVER FOR SOUP CUP  
D105mm/H26mm

51090-27651  
SOUP CUP  
D101mm/H59mm/210cc

8531-1946  
TEA/COFFEE SAUCER  
D146mm/H21mm



51090-27672  
COVER FOR FREE CUP  
D83mm/H24mm

51090-27671  
FREE CUP  
D81mm/H76mm/210cc

8531-1946  
TEA/COFFEE SAUCER  
D146mm/H21mm



51090-27692  
COVER FOR PETIT CUP  
D70mm/H21mm

51090-27691  
PETIT CUP  
D68mm/H58mm/110cc

8531-1222  
ESPRESSO SAUCER  
D124mm/H18mm



# WAVE 8725 White



8725-5235  
30cm DINNER PLATE  
D306mm/H19mm



8725-5306  
27cm DINNER PLATE  
D276mm/H21mm



8725-5307  
26cm DINNER PLATE  
D260mm/H21mm



8725-5308  
24cm BRUNCH PLATE  
D240mm/H21mm



8725-5309  
20cm SALAD PLATE  
D203mm/H21mm



8725-5310  
17cm B.B. PLATE  
D170mm/H17mm